


RT581 SubG Field Test User Guide



RafaelMicro RT581 EVK Buttons and Pins Definition



Rafael Microelectronics



RT581 SubG Parameter Selection

Frequency (MHz)	903 / 907 / 911 / 915 / 919 / 923 / 927 (7 Channels)
Data Rate (kbps)	6.25 / 50 / 100 / 200 / 300
Tx Power (dBm)	20

Select frequency with these IO

GPIO	Frequency (MHz)
31	903
30	907
29	911
28	915
23	919
14	923
9	927

Select frequency with these Buttons

Switch	Data Rate (Kbps)
Button0 (GPIO0)	6.25
Button1 (GPIO1)	50
Button2 (GPIO2)	100
Button3 (GPIO3)	200
Button4 (GPIO4)	300


Select frequency with GPIO15

GPIO	Tx / Rx
15	0: Rx, 1: Tx



RT581 SubG Test Process

- Connect GPIOxx to GND before Power on or Rest to select the frequency to test (ex. connect GPIO28 to GND frequency is 915MHz)
- Connect GPIO15 to GND before Power on or Rest as SubG Rx (ex. connect GPIO15 to GND as Rx, GPIO15 NC as Tx)



Rafael Microelectronics



RT581 SubG Tx Test Procedure

- Press Button0~4 once to select the data rate to test (ex. Press Button0 once to select 6.25Kbps to test)
- Press the same button second time to start Tx (ex. Press button0 second time to start Tx)
- Press the same button third time to stop Tx (ex. Press button0 third time to stop Tx)

```
文件(P) 編輯(E) 設定(S) 控制(O) 視窗(W) 帮助(H)

Test Case: RFB_PCI_FSK_BURST_TX_TEST
RFB Firmware version: 20221129

Tx: OQPSK 6.25K, RFB KEYING OQPSK Press Once
Tx (len:109)done total:1 Fail:0 CaFail:0 NoAck:0 TxFail0
Tx (len:109)done total:2 Fail:0 CaFail:0 NoAck:0 TxFail0
Tx (len:109)done total:3 Fail:0 CaFail:0 NoAck:0 TxFail0
Tx (len:109)done total:4 Fail:0 CaFail:0 NoAck:0 TxFail0
Tx: OQPSK_6.25K, RFB_KEYING_OQPSK Press third time
```



RT581 SubG Rx Test Procedure

- Press Button0~4 once to select the data rate to test (ex. Press Button0 once to select 6.25Kbps to test)
- Press the same button second time to start Rx (ex. Press button0 second time to start Rx)
- Press the same button third time to stop Rx (ex. Press button0 third time to stop Rx)



Rafael Microelectronics



RafaelMicro RT581 SubG Tx LED Indication

- Tx / Rx frequency, data rate must be the same
- Press the same button second time to start Tx and blue LED turn on (Tx sends 300 packets each time)
- Check the Packet ACK Rate(PAR) after 300 packets of Tx completed
 - PAR > 30% red LED turn on (Fail)
 - PAR < 30% green LED turn on (Pass)



RafaelMicro RT581 SubG Rx LED Indication

- Press the same button second time to start Rx and red LED turn on
- If Rx does not receive any signal for more than 1 second, the red LED flashing
- If Rx receives the signal again, the red LED stays on
- Stop Rx function red LED turn off



Thank You

よろしくお願い申し上げます

© 2019 by Rafael Microelectronics, Inc.

All Rights Reserved.

Information in this document is provided in connection with Rafael Microelectronics, Inc. ("Rafael Micro") products. These materials are provided by Rafael Micro as a service to its customers and may be used for informational purposes only. Rafael Micro assumes no responsibility for errors or omissions in these materials. Rafael Micro may make changes to this document at any time, without notice. Rafael Micro advises all customers to ensure that they have the latest version of this document and to verify, before placing orders, that information being relied on is current and complete. Rafael Micro makes no commitment to update the information and shall have no responsibility whatsoever for conflicts or incompatibilities arising from future changes to its specifications and product descriptions.

THESE MATERIALS ARE PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, RELATING TO SALE AND/OR USE OF RAFAEL MICRO PRODUCTS INCLUDING LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, CONSEQUENTIAL OR INCIDENTAL DAMAGES, MERCHANTABILITY, OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT. RAFAEL MICRO FURTHER DOES NOT WARRANT THE ACCURACY OR COMPLETENESS OF THE INFORMATION, TEXT, GRAPHICS OR OTHER ITEMS CONTAINED WITHIN THESE MATERIALS. RAFAEL MICRO SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, INCLUDING WITHOUT LIMITATION, LOST REVENUES OR LOST PROFITS, WHICH MAY RESULT FROM THE USE OF THESE MATERIALS.

Rafael Micro products are not intended for use in medical, lifesaving or life sustaining applications. Rafael Micro customers using or selling Rafael Micro products for use in such applications do so at their own risk and agree to fully indemnify Rafael Micro for any damages resulting from such improper use or sale. Rafael Micro, logos and Rafael Micro for Rafael Microelectronic, Inc. Product names or services listed in this publication are for identification purposes only, and may be trademarks of third parties. Third-party brands and names are the property of their respective owners.

Rafael Microelectronics P9

The information contained herein is the exclusive property of Rafael Microelectronics, Inc. and shall not be distributed, reproduced or disclosed in whole or in part without prior written permission of Rafael Microelectronics, Inc.